



TELEFUNKEN

Elektroakustik

Congratulations!!!

You have just purchased one of the finest recording instruments ever created, the TELEFUNKEN R-F-T CU-29 "Copperhead." Due to the sensitivity of the R-F-T CU-29, there are specific handling and care instructions. Failure to adhere to the following may void your warranty.

Handling and Care Instructions:

- Please be sure to secure the microphone to a microphone stand or over-head boom stand before use.
- Please make all connections before turning power on.
- Let microphone warm up for at least 20 minutes before each use.
- Do not inter-connect with historic/vintage microphones for any reason.
- We suggest the use of a pop screen for recording vocals.
- Be sure to turn off the microphone and wait 5 minutes before disconnecting.

Be conscious of your gain levels, this is a very sensitive recording instrument.
Damage may be done to the microphone.



R-F-T CU-29	Specifications
Type	Condenser Pressure Gradient
Capsule	1-inch single sided gold sputtered membrane
Polar Patterns	Cardioid
Frequency Response	20 - 20,000Hz
Tube Type	NOS TELEFUNKEN EF-95
Sensitivity	14mV/Pa = -37dB (0dB = 1v/Pa) -10dB
Impedance	200 Ohms
S/N Ratio	79dB
Max SPL	125dB (for 1% THD @ 1000Hz)
Equivalent Noise	15dB (A weighted)
Power Requirements	Dedicated Power Supply
Controls	N/A
Dimensions	8" (241mm) length x 1 3/4" (44.45mm) diameter
Weight	24oz (765g)

Enclosed, you will find your Warranty Statement. Please contact us with any questions or concerns at contact@t-funk.com or (860) 882-5919.

Thank you and once again Congratulations!!!
All of us at TELEFUNKEN Elektroakustik /
R-F-T Funkwerk