



# TELEFUNKEN

## Elektroakustik

### Congratulations!!!

You have just purchased one of the finest recording instruments ever created, the TELEFUNKEN Elektroakustik ELA M 251E / ELA M 250E. Due to the sensitivity of the ELA M 251E / ELA M 250E, there are specific handling and care instructions. Failure to adhere to the following may void your warranty.

#### Handling and Care Instructions:

- Please be sure to secure the microphone to a microphone stand or over-head boom stand before use.
- Please make all connections before turning power on.
- Let microphone warm up for at least 20 minutes before each use.
- Do not inter-connect with historic/vintage microphones for any reason.
- We suggest the use of a pop screen for recording vocals.
- Be sure to turn off the microphone and wait 5 minutes before disconnecting.

Be conscious of your gain levels, this is a very sensitive recording instrument.  
Damage may be done to the microphone.



Enclosed you will find your Warranty Statement, as well as instructions for setting your combination lock on the flight case. Please contact us with any questions or concerns at [contact@t-funk.com](mailto:contact@t-funk.com) or (860) 882-5919.

**Thank you and once again Congratulations!!!**  
**All of us at TELEFUNKEN Elektroakustik /**  
**R-F-T Funkwerk**

ELA M 251E / 250E	Specifications
Type	Condenser Pressure Gradient
Capsule	CK12 1-inch dual sided gold sputtered membrane
Polar Patterns	Omni, Cardioid, Figure-8 (ELA M 251E)
Frequency Response	20 - 20,000Hz
Tube Type	NOS General Electric JAN 6072a twin triode
Sensitivity	approx 1.2 mvolts per dyne / cm sq
Impedance	200 Ohms
S/N Ratio	78dB
Max SPL	138dB (for 1% THD @ 1000Hz)
Equivalent Noise	16dB (A weighted)
Power Requirements	Dedicated Power Supply
Controls	Pattern Selector Switch (on microphone)
Dimensions	8 1/2" (216mm) length x 2" (51mm) diameter
Weight	34oz (960g) with swivel connector

# TELEFUNKEN Elektroakustik Vacuum Tube 90-day Limited Warranty Statement



TELEFUNKEN Elektroakustik warrants that any capsules and tubes used in their microphones are free from defects in material and workmanship for the period of ninety (90) days from the original date of purchase, and agree to replace any capsule or tube which, under normal installation and use, disclose such defect. This is provided that the complete microphone is delivered to TELEFUNKEN Elektroakustik intact for examination and provided that such examination discloses, in the judgment of TELEFUNKEN Elektroakustik, that the tube or capsule is indeed defective. Upon replacement, TELEFUNKEN Elektroakustik will provide an additional 90-day limited warranty on the new capsule or tube.

This warranty does not extend to any capsule or tube which appears to have been misused, altered, neglected, damaged, or stored in any manner that adversely affects it, or used in violation of instructions furnished by us. This limited warranty shall be void and of no further force or effect whatsoever if the microphone is repaired or modified by any person other than an authorized representative of TELEFUNKEN Elektroakustik. This warranty shall not apply to any defect, failure, or damage caused in whole or in part from attempts by personnel other than TELEFUNKEN Elektroakustik's to open, repair, or service the microphone; nor to damage to a unit which has been modified by persons other than TELEFUNKEN Elektroakustik personnel.\*\*\*

The length of this warranty shall be extended to one (1) year upon submission of your warranty card.

The Warrantee shall be responsible for shipping charges of this microphone back to TELEFUNKEN Elektroakustik, with return ground shipment provided by the Warrantor (TELEFUNKEN Elektroakustik).

This 90-day limited warranty is given by TELEFUNKEN Elektroakustik in lieu of any other warranty expressed or implied.

\*\*\* If any security seals are broken or altered in any way, this warranty is null and void.



## TELEFUNKEN Elektroakustik

300 Pleasant Valley Road Suite E  
South Windsor, CT 06074  
TELE: +1 860.882.5919  
FAX: +1 860.882.5980  
[www.telefunken-elektroakustik.com](http://www.telefunken-elektroakustik.com)

# TELEFUNKEN